

Floralwall Cleaning Procedures

Floraline Floralwalls are designed to provide freedom in merchandising floral arrangements while keeping maintenance and upkeep time to a minimum... giving you time to attend to greater concerns, *your costumers*. While Floraline floral display cases automatically change water in the tubes and vases at a predetermined time, it is recommended that a regular cleaning program be implemented. The recommended cleaning procedures time-line is as follows:

- ◆ cleaning of case exterior and vases - weekly
- ◆ draining and cleaning of tubes - monthly
- ◆ pan removal and cleaning of case bottom and drains - yearly
- ◆ changing of water filters - every six (6) months

Simply follow these step-by-step procedures:

Cleaning of Case Exterior

A mild soap and water solution with a soft cloth is recommended for painted and laminate surfaces of the display cabinet. **DO NOT USE CLEANERS CONTAINING ABRASIVE MATERIALS.** This will scratch and/or dull the display cabinet's finish.

Draining and Cleaning of Tubes and Vases

1. Using a small step ladder, locate the electrical control box at the top center of the case. Move the toggle switch at the left end of the box into the "off" position (A). This shuts off both the timer and water solenoids. The lights and fans are not effected by this on/off switch. For units using key switches, make certain key is in off position (B).
2. Remove all floral vases; begin draining the tubes one at a time by lifting the top ring of the flush valve located at the far right end of each tube. A flush valve lock clip which is connected to the third tube's flush valve by a ball chain (C) can be slipped under each flush valve ring to ease this operation (D).
3. After draining the tubes, remove any remaining foliage and wipe out tube with a brush, towel, or sponge.
4. The floral vase can be cleaned with a soft cloth and mild mixture of chlorine bleach and water (E).
5. After cleaning is complete, replace vases and turn toggle switch to "on" position to allow tubes to refill with water.

Pan Removal and Cleaning of Case Bottom and Drain

1. Disconnect water line to flush valve by unscrewing nut; nut should be finger tight. **DO NOT USE A WRENCH TO TIGHTEN NUT (F).**
2. Disconnect fill fitting on the left end of tube in the same manner (G). Remove lattice.
3. Drain bottom tube (see "Draining and Cleaning of Tubes and Vases").
4. Unplug float assembly located near flush valve (H,I).
5. Lift tube straight up and remove from case (J).
6. Pull drain hoses out of drain manifold located under flush valves (K).
7. Remove pans (L).
8. **Shut off power to fans.** Inspect and clean fans as necessary. Pull fan plenum back (M) and inspect drain and coil (N).
9. Flush drain with water (do not introduce water to drain faster than it can carry the water away).
10. Replace pans and turn on; replace drain hoses back into drain manifold; hoses are numbered for correct placement.
11. Install tube by lowering flush valve into drain manifold.
12. Screw hose and nut on flush valve and fill fitting by hand; observe color coding if applicable. **DO NOT OVERTIGHTEN.**
13. Plug in float assembly, replace lattice and turn power on.

By implementing a regular cleaning program you can insure many years of dependable service from your Floraline case. This helps guarantee floral freshness and the utmost in customer satisfaction with each and every purchase ... ensuring you repeat business.

If you have any questions regarding the cleaning or operation of your Floraline case, please feel free to contact our customer service office at (440) 975-9449 and speak with one of our knowledgeable representatives. They will be happy to explain any procedures and answer any questions you may have.

